



## Measure Opening and Pockets for Skylights

Skylight installation requires precise preparations. Measure all opening lengths and overall recess lengths. Laser can be used.

**Important:** Millimeter precision is important for perfect end result. It can be worth measuring again after first box has been installed.



Measure the pocket size at each end and the center.



Measure diagonals to confirm the opening is square and true.

**Important:** Some skylight blinds are very sensitive to openings being absolute correct. Laser can be used.



Use spirit level to confirm horizontal level on shelves.