



Measure Opening and Pockets for Windows and Doors

Measure the opening length and the pocket length to allow for end caps and/or side boxes.

Important: Millimeter precision is important for perfect end result. It can be worth measuring again.



Measure the pocket size at each end and the center where a box will be mounted.



Measure heights.



Measure diagonals to confirm the opening is square and true.



Use spirit level to confirm horizontal level.



Confirm vertical plumb.